

Запасные части для предыдущих моделей

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Series 1 – Original Version

WRPK140 - Bungee D-Ring

Used For: Connecting Bungee hook to Recoil Belt. All Models.



WRPK100 SI - Series 1 Bungee Assembly

Double Bungee Assembly Used For; Recoiling Drive Strap
Used On; Early Series I Machines Included; Bungee,
Double Bungee Pod, D-Ring



Series 2- US Version



WRPT760 - Tank Stopper

For Sealing the Tank/Tank Grommet. All Wood, GX, S1 and M1 Models.



WRPT730 - Tie Rod Set

For Attaching the Forward Risers to the Top Deck and Bottom Deck. All Wood, GX and S1 Models.



WRPT280 - Clutch Attachment Pin

For Attaching the Clutch to the Paddle Shaft. All Wood, S1 and M1 Models.



WRPS330 - Load Wheel Assembly

For Rolling Seat On Rail. All Wood, S1 and M1 Models.

**WRPS320 - Wheel Guard Set**

For Protecting the Wheels from entrapping items. All Wood, M1 and S1 Models.

**WRPR310 - Rail Tank Protector Strip (set of 2)**

Affixes to Rail, allows movement and protects tank from scratching. All Models.

**WRPR200 - Rail Bumper set**

For Bumpers to support bottom of Wooden Rails. All Wood Models Only.

**WRPR106 - Wooden Rail Rail Extrusion/Insert (1195mm/47") - Set of 2**

For Seat running Surface, Lip retains the Guide Wheels. Early Models with wooden rails.



**WRPR100 - Wooden Rail Rail Extrusions/Insert
(1080mm/42.5") - Set of 2**

For Seat running Surface, Lip retains the Guide Wheels.
Early Models with wooden rails.



WRPK170 - Recoil Buckle
Recoil Assembly Buckle



WRPK140 - Bungee D-Ring

Used For: Connecting Bungee hook to Recoil Belt. All
Models.



WRPB710 - Top Deck 30mm Joint Connector Bolt (JCB)

Used For; Connecting Top Deck to Footboard Key Brackets
ONLY. All Wood and GX Home/Studio Models



WRPP575- SII US Footstrap Bolt (set of 2)

SII US Footstrap Bolt Set

Used For; Fastening the Footstrap to the Footboard

Used On; All Wood Models

Includes; 2 Bolts

NOTE- This is a 5/16-18 Bolt used on the US version. The UK Version used an M8 threaded bolt



WRPP365- SIII and SII Footstrap

SIII and SII

Used For; Securing feet to the Footboard

Used On; All SIII and SII Models

Includes; Footstrap, Footstrap Clamp Bar, Rear Footstrap Guide Bracket , Footstrap Bolts (2)



WRPK100 - Double Bungee Assembly

Double Bungee Assembly Used For; Recoiling Drive Strap

Used On; Early Series II Machines Included; Bungee, D-Ring



WRPT520A - US V2 Tank Key Bracket- Right (Large)

US V2 Tank Key Bracket- Right (Large)

Used For; Attaching Bottom Deck, Top Deck and Footboard

Used By; All US Series 2 Models

Includes; Tank Key Bracket Assembly

NOTE- Fits US Series 2 and US Nordic Track Machines ONLY



WRPT510A - US V2 Tank Key Bracket- Left (Small)

US V2 Tank Key Bracket- Left (Small)

Used For; Attaching Bottom Deck, Top Deck and Footboard

Used By; All US Series 2 Models

Includes; Tank Key Bracket Assembly

NOTE- Fits US Series 2 and US Nordic Track Machines
ONLY



WRPS405 - Seat Guide Wheels (set of 4)

Guides the Seat Assembly between the Rails. All Wood and
S1 Models.

Series 2- UK Version



WRPT760 - Tank Stopper

For Sealing the Tank/Tank Grommet. All Wood, GX, S1 and M1 Models.



WRPT730 - Tie Rod Set

For Attaching the Forward Risers to the Top Deck and Bottom Deck. All Wood, GX and S1 Models.



WRPT280 - Clutch Attachment Pin

For Attaching the Clutch to the Paddle Shaft. All Wood, S1 and M1 Models.



WRPS330 - Load Wheel Assembly

For Rolling Seat On Rail. All Wood, S1 and M1 Models.

**WRPS320 - Wheel Guard Set**

For Protecting the Wheels from entrapping items. All Wood, M1 and S1 Models.

**WRPS100 - Seat Cushion**

For All Wood, M1, S1 Models. NOTE- GX Series Models use WRPS1100

**WRPR310 - Rail Tank Protector Strip (set of 2)**

Affixes to Rail, allows movement and protects tank from scratching. All Models.

**WRPR200 - Rail Bumper set**

For Bumpers to support bottom of Wooden Rails. All Wood Models Only.

WRPR130 - Rail Stop Set

For Limiting travel of Seat. All Wood. M1 and S1 Models.



WRPR106 - Wooden Rail Rail Extrusion/Insert (1195mm/47") - Set of 2

For Seat running Surface, Lip retains the Guide Wheels.
Early Models with wooden rails.



WRPR100 - Wooden Rail Rail Extrusions/Insert (1080mm/42.5") - Set of 2

For Seat running Surface, Lip retains the Guide Wheels.
Early Models with wooden rails.



WRPP455 - Handle Rest Bolt (set of 2)

For attaching Handle Rests to the Footboard/Tank Key
Brackets. All Models.



WRPP430 - Handle Rest Set

For Attaching Footboard to the Tank Key Brackets.
Supporting Handle when not in used. All models.



WRPP100 - Footboard Emblem

For Branding the Footboard. All Wood, GX M1 and S1
Models.



WRPK170 - Recoil Buckle

Recoil Assembly Buckle



WRPK140 - Bungee D-Ring

Used For: Connecting Bungee hook to Recoil Belt. All
Models.



WRPB710 - Top Deck 30mm Joint Connector Bolt (JCB)

Used For; Connecting Top Deck to Footboard Key Brackets
ONLY. All Wood and GX Home/Studio Models



WRPP365- SIII and SII Footstrap

SIII and SII

Used For; Securing feet to the Footboard

Used On; All SIII and SII Models

Includes; Footstrap, Footstrap Clamp Bar, Rear Footstrap
Guide Bracket , Footstrap Bolts (2)



WRPK100 - Double Bungee Assembly

Double Bungee Assembly Used For; Recoiling Drive Strap
Used On; Early Series II Machines Included; Bungee,
D-Ring



WRPS405 - Seat Guide Wheels (set of 4)

Guides the Seat Assembly between the Rails. All Wood and
S1 Models.





WRPS375 - Load Wheel E-Circlip Set

For Fastening the Seat Load Wheel onto the Seat Axle. All Wood, M1 and S1 Models.

This new E-clip is an upgrade from the original C-shaped circlip; the new E-clip makes installing your Load Wheel Assembly easier with no tool necessary. The E-clip will fit on any machine that originally used a C-shaped circlip.

Series 3- NordicTrack Version

WRPT760 - Tank Stopper

For Sealing the Tank/Tank Grommet. All Wood, GX, S1 and M1 Models.



WRPT730 - Tie Rod Set

For Attaching the Forward Risers to the Top Deck and Bottom Deck. All Wood, GX and S1 Models.



WRPT280 - Clutch Attachment Pin

For Attaching the Clutch to the Paddle Shaft. All Wood, S1 and M1 Models.



WRPS330 - Load Wheel Assembly

For Rolling Seat On Rail. All Wood, S1 and M1 Models.



**WRPS320 - Wheel Guard Set**

For Protecting the Wheels from entrapping items. All Wood, M1 and S1 Models.

**WRPR310 - Rail Tank Protector Strip (set of 2)**

Affixes to Rail, allows movement and protects tank from scratching. All Models.

**WRPK170 - Recoil Buckle**

Recoil Assembly Buckle

**WRPK140 - Bungee D-Ring**

Used For: Connecting Bungee hook to Recoil Belt. All Models.



WRPP365- SIII and SII Footstrap

SIII and SII

Used For; Securing feet to the Footboard

Used On; All SIII and SII Models

Includes; Footstrap, Footstrap Clamp Bar, Rear Footstrap Guide Bracket , Footstrap Bolts (2)



WRPS305- Seat Axle Assembly

Seat Axle Assembly

Used For; Fastening Load Wheels to the Seat Risers

Used By; All Wood and S1 Models

Includes; Seat Axle, Seat Axle Sleeve, Seat Axle Circlip (2), Seat Axle E-Clip (4)



WRPK100 - Double Bungee Assembly

Double Bungee Assembly Used For; Recoiling Drive Strap

Used On; Early Series II Machines Included; Bungee, D-Ring



WRPT520A - US V2 Tank Key Bracket- Right (Large)

US V2 Tank Key Bracket- Right (Large)

Used For; Attaching Bottom Deck, Top Deck and Footboard

Used By; All US Series 2 Models

Includes; Tank Key Bracket Assembly

NOTE- Fits US Series 2 and US Nordic Track Machines ONLY



WRPT510A - US V2 Tank Key Bracket- Left (Small)

US V2 Tank Key Bracket- Left (Small)

Used For; Attaching Bottom Deck, Top Deck and Footboard

Used By; All US Series 2 Models

Includes; Tank Key Bracket Assembly

NOTE- Fits US Series 2 and US Nordic Track Machines
ONLY



WRPS405 - Seat Guide Wheels (set of 4)

Guides the Seat Assembly between the Rails. All Wood and
S1 Models.

Series 3- Worldwide Version

WRPT760 - Tank Stopper



WRPT730 - Tie Rod Set



WRPT280 - Clutch Attachment Pin



WRPT230 - Recoil Bush Assembly and Shim (Metal Clutch Only)



WRPT150 - 4" Velcro Attachment Metal Clutch Assembly





WRPS330 - Load Wheel Assembly



WRPS320 - Wheel Guard Set



WRPS100 - Seat Cushion




WRPR310 - Rail Tank Protector Strip (set of 2)



WRPR200 - Rail Bumper set

WRPR130 - Rail Stop Set



**WRPR106 - Wooden Rail Rail Extrusion/Insert
(1195mm/47") - Set of 2**

SIII Monitor



WRPC290 - SIII (S3) Tacho Belt



WRPC262 - SIII (S3) Tacho Pulley



(Unavailable) WRPC260SIII - SIII (S3) Tacho Motor Assy



WRPC267- SIII Tacho Pulley

WRPC003 - SIII Monitor Board



WRPC210 - SIII Battery Pack



Older FootBoards



SII Monitor



Series 1 Monitors



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93